

Aritco 7000 – Flexi

Aritco 7000 – Flexi is a version of the Aritco 7000 lift that is intended for both persons and goods. A risk assessment has been conducted to assess the additional risk that will come when using the platform for both persons as well as for goods. Measures to reduce these risks have been taken and they are now implemented for Aritco 7000- Flexi. Aritco 7000- Flexi has its own certificate, which is available on the partner desktop.

The following is included when ordering an Aritco 7000 – Flexi:

- Platform with safety edge painted in yellow (RAL 1018).
- Platform with security list mounted behind the platform faceplate painted in yellow (RAL 1018). Valid when having a half height wall.
- Loading information label- warning sign placed on the platform panel.
- User manual is updated with the Aritco 7000 – Flexi option and its informs the user of where to place the goods and what size of goods that can be transported with the lift.
- Certificate for persons and goods.

Loading information label

A loading information label is placed on the platform with pictograms warning for the following:

- Do not load any goods on or outside the yellow border of the platform (safety edges). Prevents the goods to get in contact with the lift walls and get stuck between shaft wall and platform.
- Do not load any goods that are higher than 2 m on the platform. The minimum requirement for free space on top floor is 2 m, the goods will then always have free space upwards.

More information in Aritco 7000 User manual.



Safety edge in RAL 1018

Safety list in RAL 1018

Steel kerb

For extra protection of the platform and the shaft walls a steel kerb can be ordered as an option for Aritco 7000 – Flexi. The steel kerb is a 90 mm high steel frame placed on all sides on the platform, except for door sides. It is recommended when using the lift also for goods. The safety edge will be specially made to fit the steel kerb.

